



PROGRAMACIÓN DE SISTEMAS Y DISPOSITIVOS

CHECKLISTS – CONFIGURACIÓN DE HERRAMIENTAS

TERMITE SETTINGS

<i>Port</i>	COMx (depende del puesto, suele ser el de número mayor)
<i>Baud rate</i>	115200
<i>Data bits</i>	8
<i>Stop bits</i>	1
<i>Parity</i>	None
<i>Flow control</i>	None
<i>Forward</i>	None
<i>Transmitted text</i>	☒ Append LF ☒ Local echo
<i>Font</i>	Monospaced

OPENOCD SETTINGS

Run → External tools → External Tools Configurations → Program → New	
<i>Name</i>	OpenOCD
<i>Location</i>	\${eclipse_home}/../openocd-0.7.0/bin/openocd-0.7.0.exe
<i>Arguments</i>	-f test/arm-fdi-ucm.cfg
Build	
<i>Build before launch</i>	☐
Common	
<i>Display in favorites menu</i>	☒ External Tools
Apply → Close	

EMBSYS REGISTER VIEW SETTINGS

1. Incorporar el visor de registros:

Window → Show View → Other...
Debug → EmbSys Registers

2. Seleccionar el chip:

Window → Preferences	
C/C++ → Debug → EmbSys Register View	
<i>Architecture</i>	armv7
<i>Vendor</i>	Samsung
<i>Chip</i>	s3c44b0x
OK	